

FIG Z

SELECT PAY INSIDE OR PAY OUTSIDE	Acnow  - SELECT "PAY INSIDE"
REMOVE NOTELE  AND PUMP GAS	FIG 4  70  ACTION  - REMOVE NOTELE  AND PYMP
WOULD YOU  LIKE TO  HAVE SOME CASH?  IF SO PRESS "YES"	FILS  12  ACTION  - NO RESPONSE  - REPLACE NOTZEL
PLEASE PAY INSIDE	FIGO 14 ALMON - USCR PAYS INSIDE

SELECT

- USER SELECTS PAY INSIDE OR PAY OUTSIDE 78 F15 8 PRESS Acnon I FOR CREDIT CARD - USER SELECTS INFUT FOR EXAMPLE "I" FOR 2 FOR DEBIT CARD CREDIT CARD 3 FOR STORED VALUE CARD F15 9 PLEASE INSERT CREDIT CARD IN ALDON CARO READER AND - USER INSERTS CARD WITHDRAUL CARD WITH DRAW QUICKLY  $\mathcal{B}\mathcal{B}$ F16 10 REMOVE NOZZEL ACDON AND PUMP GAS - REMOVE NOZZEL AND PUMP

F16 7

Acron

**1**30€

WOULD YOU
LIKE TO
HAVE SOME CASH?
TF SO PRESS "YES."

F16 11

Acnon

- NO RESPONSE
- REPLACE NOTELE

/ 100

WOULD YOU LIKE

A RECEIPT?

PRESS

YES ON "NO"

F16 12

ALTION

- USER PRESSES SELECTED KEY
EXAMPLE "YES"

102

RECCIPT IS NOW PRINTING

F16 13

ALDON

- PRINTER PRINTS RECEIPT

104

THANK YOU

PLEASE TAKE RECEIPT

F16 14

Acnow

- USER TAXES RECEIPT

ā

PLEASE ENTER YOUR PIN NUMBER AND THEN PRESS # PRESS \* TO CLEAR

Acrion. - USER INPUTS PIN AND いまいて、非

PLEASE INSERT STORED VALUE CARD INTO READER AS FAR AS IT WILL GO.

F.16 16

Acnon - USER INSCRTS STORED VALUE CARD

SORRY, WE ARE UNABLE TO PROCESS YOUR TRANSACTION F16 17

- MACHINE RETURNS TO FIRST SCREEN AFTER TIME OUT.

PLEASE INPUT AMOUNT
BY PRESSING KEYS
THEN PRESS #
MAXIMUM \$100

ACTION

- USER INPUTS AMOUNT

AND #

Example \$100 input

FIG 19

Acnow

- CUSTOMER PRESSES
APPROPRIATE BUTTON

EXAMPLE "YES"

\$100 FROM

CREDIT CARD

PRESS "YES" TO CONFIRM

"NO" TO INPUT NEW AMOUNT

NOW PRINTING
VOUCHER FOR YOUR
CASH

ALDON

- PRINTER PRINTS VOUCHER

12 F16 21

PLEASE PRESENT.
VOULHER INSIDE
TO RECEIVE YOUR
CASH.

ACTION

- USER TAKES VOUCHER TO

CASH REGISTER / CASH DisperseR

ON WINDOW AND RECEIVED CASH

۲,۱۲


F16 22

REMEMBER TO TAKE
YOUR YOUCHER

Acnor

- USER TAKES VOUCHER

	F16 23
YOUR CASH is	Acrion
Being Dispenses	- MACHINE DISPENSES CASH
and the second s	
190	F14.24.
PLEASE TAKE	ALTION - VSCR TAKES CASH
YOUR CASH	



F16 25

PAY BY

1 CARD

2 CASH

Fig Zb

ALTION

- VSER SELECTS CASH OR CARD
EXAMPLE CASH

194 - Fib. 27

INSCRI BILLS INFO

BILL ACCEPTOR BELOW

PRESS "1" TO RETURN TO

FIRST SCREEN

AcTION

- USER INSCRES NOTES INTO

NOTE ACCEPTOR OR RETURNS

TO BEGINNING

EXAMPLE-NOTE INPUT

AVAILABLE CREDIT

\$ 20.00

PRESS "I TO RETURN TO

FIRST SCREEN

PRESS "2" TO BEGIN FUMPING

F15 28

Acnow

- USER INSERTS MORE NOTES

OR PRESSES OTHER OPTIONS

EXAMPLE - USER PRESSES "2"

198

REMOVE NO ZZEL

FIG 29

ACTION

- USER REMOVES NOTZEL AND PUMPS
- Pump STOPS WHEN AVAILABLE

  CREDIT IS REACHED OR

  CUSTOMER SHUT OFF

CREDIT IS GREATER

THAN YOUR CHARGE


F16 30


Acron


- MACHINE PRINTS VOUCHER FOR DIFFERENCE


F14 31


CASH

















Fir 37



FIG




F16 40




212

F16 41




F16 42




212


F16 43



F16 44





6 - Thank You





6 - Thank You

F16 46












306







J







FIG 55







F16 59